

## Nomad Software Update Procedure

1. Copy the enclosed file to a FAT32 formatted USB thumb drive. Ensure that there are no other files on the drive.
2. Turn off the Nomad and insert the thumb drive into the Device Port Hub, the black connector hub protruding from the left side of the Nomad.
3. Turn the Nomad on and wait for the indicator light (top left light on the top panel of the Nomad) to change to amber. Depending on the firmware version, the update may proceed in one of two ways automatically:

### a. Software Update Only

The indicator light will turn from amber to white very briefly (such that you may not notice the change) and no other indicator lights on the top face or right side panel will remain on. However, if the Nomad is plugged into the power supply, the power supply indicator light will remain on. **It is imperative that the USB drive remain connected until the indicator lights extinguish.**

### b. Firmware and Software Update:

The indicator light will turn white for several seconds and then extinguish, after which the rightmost service light on the top face of the Nomad and the right-side battery indicator lights will continue to blink alternately. After several seconds, indicator lights will turn off. **It is imperative that the USB drive remain connected until the indicator lights extinguish.**

4. When the indicator light, battery indicator lights, and rightmost service light on the right side of the top face of the Nomad are turned off the update is complete. Remove the USB thumb drive then turn the Nomad on to continue use.
5. You'll also need the most recent version of [Trellis](#) to utilize the updated hardware.

[Nomad software update](#)

[Trellis/Scout software update](#)

[Lookup tables update](#) (for control of stimulation-capable Front Ends)